



TN350TECH

Technical Instructions

Cartridge Information

Tools & Supplies

1

**CORPORATE
LOS ANGELES, USA**
US 1 800 394.9900
Int'l +1 818 837.8100
FAX 1 800 394.9910
Int'l +1 818 838.7047

ATLANTA, USA
US 1 877 676.4223
Int'l +1 678 919.1189
FAX 1 877 337.7976
Int'l +1 770 516.7794

KANSAS CITY, USA
US 1 913 871.1700
FAX 1 913 888.0626

MIAMI, USA
US 1 800 595.4297
Int'l +1 305 594.3396
FAX 1 800 522.8640
Int'l +1 305 594.3309

NEW YORK, USA
US 1 800 431.7884
Int'l +1 631 588.7300
FAX 1 800 431.8812
Int'l +1 631 588.7333

TORONTO, CAN
CAN 1 877 848.0818
Int'l +1 905 712.9501
FAX 1 877 772.6773
Int'l +1 905 712.9502

BUENOS AIRES, ARG
ARG 0810 444.2656
Int'l +011 4583.5900
FAX +011 4584.3100

MELBOURNE, AUS
AUS 1 800 003. 100
Int'l +62 03 9561.8102
FAX 1 800 004.302
Int'l +62 03 9561-7751

SYDNEY, AUS
AUS 1 800 003.100
Int'l +62 02 9648.2630
FAX 1800 004.302
Int'l +62 02 9548.2635

MONTEVIDEO, URY
URY 02 902.2001
Int'l +5982 902.2001
FAX +5982 900.0858

JOHANNESBURG, S.A.
S.A. +27 11 974.6155
FAX +27 11 974.3593

SÃO PAULO, BRAZIL
Int'l +55 11 5524.8000

RAANANA, ISRAEL
ISR 09 760.12.39
Int'l +972 9760.12.39
ISR 052.38.555.82
Int'l +972 5238.555.82

See Last Page.

See Last Page.

Photo 1



Step 1

Remove the developer roller protective cover by unlatching from one side. Clean and place aside for reuse. (may not have it installed on the toner hopper) (Photo 1)


Photo 2



Step 2

Place the cartridge flat side down and the fill plug away from you. (Photo 2)


Photo 3



Step 3

Remove the three Phillip screws located on the drive train end cap facing you. Remove the cap and place aside. (Photo 3)

Photo 4



Step 4

Remove the black support bracket from the end of the developer roller shaft. (Photo 4)

Step 15

The drive train end cap contains a mechanical lever that has to be reset so that the gear strip on the lever will engage with the gear train and trigger the movement from left to right of the lever. The movement of the lever triggers a switch inside the print engine that resets during initial rotation of the cartridge when the cartridge is first installed. (Photos 15 & 16)

Photo 15



Photo 16



Photo 17




Photo 18



Photo 19



Step 16

Replace the drive train end cap back onto the toner hopper and install the Phillip screws that hold it in place. (Photo 17)

Step 17

Fill with toner.
Replace fill cap. (Photo 17)

Step 18

Replace the developer roller protective cover by latching from one side. (Photo 17)

OEM INFO:

Part Number: TN-350
Yield @ 5% 2,500 pages
Gram Load: 90 grams
PPM: 20

MFC-7220 / MFC-7225N / MFC-7420
/ MFC-7820N
FAX-2820 / FAX-2920
DCP-7020

TOOLS:

Flat Blade Screwdriver
Phillips Screwdriver

PRINTERS:

HL-2040 / HL-2070N

The Brother HL-2040 and HL-2070N printers are 20ppm monochrome laser printers with up to 2400x600 dpi resolution and standard 250 sheet input capacity. Both printers have standard interface connection that is Parallel and USB the HL-2070N contains the network 10/100 BaseT Ethernet connection. The other models MFC, FAX and DCP take the same supplies but have other options.

Consumables that come in the box for the above mentioned models contain a starter cartridge rated at 1,500 pages and the



regular drum unit DR350 rated at 12,000 pages. The starter cartridge is a one use cartridge due to a mechanical reset lever that is missing but contained in the standard cartridge.

*Future Graphics (FG) is a distributor of compatible replacement parts and products for imaging equipment.
None of FG's products are genuine OEM replacement parts and no affiliation or sponsorship is to be implied between FG and any OEM.*