





HP4500TECHCMY

| Technical Instructions   | Printers   | OEM Info  | Tools   | 1 |
|--|--|---|---|---|
| <p>CORPORATE<br/><b>LOS ANGELES, USA</b><br/>US 1 800 394.9900<br/>Int'l +1 818 837.8100<br/>FAX 1 800 394.9910<br/>Int'l +1 818 838.7047</p> <p><b>ATLANTA, USA</b><br/>US 1 877 676.4223<br/>Int'l +1 770 516.9488<br/>FAX 1 877 337.7976<br/>Int'l +1 770 516.7794</p> <p><b>DALLAS, USA</b><br/>US 1 877 499.4989<br/>Int'l +1 972 840.4989<br/>FAX 1 877 774.1750<br/>Int'l +1 972 840.1750</p> <p><b>MIAMI, USA</b><br/>US 1 800 595.429<br/>Int'l +1 305 594.3396<br/>FAX 1 800 522.8640<br/>Int'l +1 305 594.3309</p> <p><b>NEW YORK, USA</b><br/>US 1 800 431.7884<br/>Int'l +1 631 345.0121<br/>FAX 1 800 431.8812<br/>Int'l +1 631 345.0690</p> <p><b>SANFORD, USA</b><br/>US 1 800 786.9049<br/>Int'l +1 919 775.4584<br/>FAX 1 800 786.9049<br/>Int'l +1 919 775.4584</p> <p><b>TORONTO, CAN</b><br/>CAN 1 877 848.0818<br/>Int'l +1 905 712.9501<br/>FAX 1 877 772.6773<br/>Int'l +1 905 712.9502</p> <p><b>BUENOS AIRES, ARG</b><br/>ARG 0810 444.2656<br/>Int'l +011 4583.5900<br/>FAX +011 4584.3100</p> <p><b>MELBOURNE, AUS</b><br/>AUS 1 800 003. 100<br/>Int'l +62 03 9561.8102<br/>FAX 1 800 004.302<br/>Int'l +62 03 9561-7751</p> <p><b>SYDNEY, AUS</b><br/>AUS 1 800 003.100<br/>Int'l +62 02 9648.2630<br/>FAX 1800 004.302<br/>Int'l +62 02 9548.2635</p> <p><b>MONTEVIDEO, URY</b><br/>URY 02 902.7206<br/>Int'l +5982 900.8358<br/>FAX +5982 908.3816</p> <p><b>JOHANNESBURG, S.A.</b><br/>S.A. +27 11 974.6155<br/>FAX +27 11 974.3593</p> | <p>HP4500/4550<br/>HP4500N/4550N<br/>HP4500DN/4550DN</p> | <p>Part #: C4192A=Cyan<br/>C4193A=Magenta<br/>C4194A=Yellow</p> <p>Yield @ 5%: 6,000 Pages<br/>Pages/Min.: 4 Color/16 Black<br/>Resolution: 600dpi<br/>(HP ImageRET 2400)</p> | <p>Cartridge Clip Remover<br/>#1 Phillips Head Screwdriver<br/>Small Flat Blade Screwdriver<br/>Phillips Head Jeweler's Screwdriver<br/>Soft Cleaning Wipes<br/>Needle Nose Pliers<br/>Mag Roller Sleeve Cleaner<br/>Vacuum or Compressed Air</p> |   |



**Step 1**

Carefully remove the contact pin from the cartridge by disengaging the locking tab. Insert a hook tipped tool in the end cap opening and compress the locking tab, releasing the contact pin for removal. (See Photo 1)



**Step 2**

With a small flat blade screwdriver release the shutter lock from the opposite end of the cartridge. (See Photo 2)



**Step 3**

Elongate the shutter just enough to disengage it from the cartridge drive hub. (See Photo 3)

**Other Technical Instruction Guides available for this engine:**

HP4500/4550 Black Toner Cartridges Reman. Instructions ..... HP4500TECH-BLK  
HP4500/4550 Drum Unit Remanufacturing Instructions ..... HP4500TECH-DRUM





